



1	GEARWHEEL ON CAMSHAFT
2	INLET CAM, BORE 116MM
3	FUEL CAM COMPLETE
4	HUB FOR FUEL CAM, BORE 116MM
5	EXHAUST CAM, BORE 116MM
6	ADJUSTING SCREW
7	CAMSHAFT BEARING
8	TRUNNION FOR INTERMEDIATE GEARWHEEL
9	GEARWHEEL ON CRANKSHAFT COMPLETE
10	OIL DEFLECTOR
11	UPPER PART GEAR CASE

12	LOWER PART GEAR CASE
13	COVER
14	SIMMER RING
15	CRANK WITH PIN COMPLETE
16	INTERMEDIATE GEARWHEEL WITH BEARING BRUSH
17	RING
18	FILLING RAND COMPLETE
19	-
20	-
21	-
23	CAMSHAFT BEARING - MANOEVERING SIDE